

STEPS TO INSTALL ECOFLO GLASS MEDIA INTO PF MEDIA FILTERS

- 1. Check size of filter and quantities of bags supplied against specified amounts printed on bag
- 2. Open Course Grade bag (GL1530) and pour contents into filter tank making sure pipe is centred by utilising plastic locator.
- 3. Pour the specified amount of Course Grade into filter tank as specified on bag
- 4. Then pour Fine Grade (GL0515) on top as specified on bag.
- 5. Read PF Media Filter Manual for more details